

# The Space-Barracks Heater



The Space-Barracks Heater, is individually packed, self contained, and produces from 20,000 to 60,000 BTU (adjustable output control) from a 19"W X 35"H X 22.5"D , 88 lb. unit (100 lb. with the stack assembly, and boxed). It includes the fail-safe, non-flooding vaporizing burner which is controlled by adjusting an attached fuel control valve. It is designed for use with DF1, DF2, DFA, JP8, JetA1, and Kerosene.

The Space-Barracks Heater is supplied with the following:

- Connections for 5 gallon Jerry can
- Connections for external fuel supply
- Stack Assembly and elbow
- Raincap with guylines
- Siphon priming bulb and Primer cup
- Fuel supply hose and vent hose
- Fuel Control Valve
- Basic operating instructions
- Attached Spill Pan (19" x 22.5")



Optional accessories:

- Jerry fuel can
- Fuel can stand (for external fuel source).
- Gravity feed adapter (for external fuel source).
- Fuel supply hose (for external fuel source).



**INTERNATIONAL THERMAL RESEARCH**

[www.itrheat.com](http://www.itrheat.com)